

BEFORE APPLYING ORTHOSIS:

- Check leg for any neurological or vascular changes.
- Check device to be sure that lock and lock safety are engaged.



FOR DYNAMIC TENSION:

- Swing lock lever safety away from lock lever.
- Disengage lock lever by slightly extending leg.



TO INSPECT THE FIT:

- Check alignment and adjust straps for comfort.
- Check for any neurological or vascular changes.

TO APPLY ORTHOSIS:

- Unfasten or loosen all straps.
- Slide device onto leg with strut placed on outside of limb and tension spring lined up at the knee joint.
- Align the struts by along the long bones of the leg.
- Fasten and tighten straps (outer straps first followed by middle straps). Straps should be snug enough for one finger to be inserted between the strap and skin.
- Loosely fasten middle straps closest to the knee. Metal stabilizing bars should not come in contact with patient's skin.



TO REMOVE ORTHOSIS:

- Lock device into position by engaging lock lever safety with lock lever.
- Unfasten/loosen straps and carefully slide orthosis off leg.





ADVANCE DYNAMIC[®] ROM - KNEE FLEXION ORTHOSIS

RESTORE MOTION, RETURN TO FUNCTION



THE ROM SPECIALISTS[®]

Joint Active Systems, Inc. | 1-800-879-0117 | Effingham, Illinois | Made in USA, Licensed In The State Of Illinois | jointactivesystems.com